

JUNIOR POWER CABLE FEED

Parts List and Diagrams

(For Sewerooter Junior & Sewerooter T-3)

CAT. NO.	DESCRIPTION	CAT. NO.	DESCRIPTION
PO-JR/GT	JR Power Cable Feed and Guide Tube	PO-JR 400	Bottom Roller Assembly
PO-JR 101	Feed Body	PO-JR 410	Bottom Carrier Only
PO-JR 101A	Spout	PO-JR 420	Swing Pin
PO-JR 101B	Guide Clip	PO-JR 425	Bottom Roller Shaft
PO-JR-102	Knob	PO-JR 450	Bottom Roller with Bearing
PO-JR 200	Top Roller Assembly	PO-JR 510	Retaining Ring
PO-JR 210	Top Carrier Only	PO-JR 530	Thrust Bearing & Races
PO-JR 220	Swing Pin	PO-JR 601	Feed Control Disc with Lever & Knob
PO-JR 225	Feed Roller Shaft	PO-JR 601A	Lever & Knob
PO-JR 250	Feed Roller with Bearing	PO-JR 601B	Lifting Spring & Screw
PO-JR 301	Feed Pressure Knob	PO-JR 635	Wave Washer
PO-JR 301A	Limiting Nut	PO-JR 640	Feed Control Retaining Cover
PO-JR 315	Pressure Spring	PO-JR 641	Retaining Cover Screws (3)
PO-JR 330	Ball Bearing	PO-JR 703	Set of Rollers (3)
PO-JR 331	Ball Bearing Holder	PO-JR DECAL	Set of Safety Decals
PO-JR 340	Top Cover	JR-GT	Guide Tube for JR
PO-JR 341	Cover Screws & Washers (3)		


General Wire Spring Co.

1101 Thompson Avenue

412/771-6300

McKees Rocks, PA 15136 U.S.A.

JUNIOR POWER CABLE FEED SCHEMATIC DIAGRAM



IMPORTANT: When ordering, give Serial Number of Machine.