

MINI-ROOTER POWER CABLE FEED

Parts List and Diagram

CAT. NO.	DESCRIPTION	CAT. NO.	DESCRIPTION
PO-MR	Complete Mini-Router Power Cable Feed	PO-MR-602	Control Disc Retaining Snap Ring
PO-XP	Complete XP Power Cable Feed	PO-MR-703	Set of Feed Rollers (3)
PO-MR-101	Power Cable Feed Body	PO-MR-800	Feed Mounting Assembly
PO-MR-101-A	Spout	PO-MR-820	Mini-Router Mounting Plate
PO-MR-102	Lifting Spring	PO-MR-821	Bolts and Washers (2)
PO-MR-200	Feed Roller Assembly	PO-MR-830	Upper Mounting Bar with Set Screws
PO-MR-210	Carrier Only	PO-MR-831	Set Screws (2)
PO-MR-220	Swing Pin	PO-MR-840-1	Upper Clamp Assembly
PO-MR-225	Feed Roller Shaft	PO-MR-841	Upper Clamps
PO-MR-250	Feed Roller	PO-MR-842	Slot Head Screw
PO-MR-301	Feed Pressure Knob Assembly	PO-MR-843	Carriage Bolt
PO-MR-315	Outer Pressure Spring	PO-MR-844	Knob
PO-MR-330-1	Washer	PO-MR-845	Spring
PO-MR-510	Bottom Roller Assembly Retaining Snap Ring	PO-MR-846	Cone Spring
PO-MR-530	Thrust Washer	PO-MR-847	Lock Nut
PO-MR-601	Feed Control Disc with Lever & Knob	PO-MR-850-1	Lower Mounting Bar
PO-MR-601-A	Lever and Knob	PO-MR-851	Socket Head Cap Screw (2)
		PO-MR-870	Lower Clamp Assembly
		PO-MR-871	Lower Clamps
		PO-MR-873	Nuts and Bolts (2)
		MR-GT	Guide Tube

General Wire Spring Co.